



[Portal](#) > [Knowledgebase](#) > [Satellite Communicators](#) > [Iridium GO!](#) > [Tracking with the Iridium GO!](#)

Tracking with the Iridium GO!

Lu Parente - 2019-12-31 - in [Iridium GO!](#)

Follow the instructions below for assistance on how to use tracking with the Iridium GO!

The Iridium GO! allow you to enable tracking using time based intervals. Your latitude and longitude will be sent to one recipient by email or SMS.

Enabling Tracking

1. Connect to the Iridium GO! using your mobile device
2. Open the **Iridium GO!** application.
3. Select the **Login** button.
4. Enter login credentials (default is **guest** for username and password).
5. Select **Settings**.
6. Select **Track**.
7. Select **Tracking Frequency** then select an interval (**Note:** Each track sent out is charged as an SMS).
8. Select **Tracking Recipient** and enter a phone number for SMS (using the international format of +1 followed by area code and phone number) or an email address.
9. Save the changes when finished.

The Iridium GO! will now begin tracking. Tracking can be disabled by performing the same steps and selecting **No update** under the **Tracking Frequency** menu. Once these settings are saved, regular tracking messages will be sent automatically even if the Iridium GO! application or smartphone is turned off.